

Tarozi si filiere

Marimi si pasuri filete

In tabel sunt trecute si marimile burghiilor necesare pentru dat gaura

PAS	MARIME	BURGHIU NECESAR
	2x0.4	1.6
NORMAL	2.2X0.45	1.75
	2.5X0.35	2.15
NORMAL	2.5x0.45	2.05
	3X0.35	2.65
NORMAL	3X0.5	2.5
NORMAL	3.5X0.6	2.9
	4X0.5	3.5
NORMAL	4X0.7	3.3
NORMAL	4.5X0.75	4
	5X0.5	4.5
NORMAL	5X0.8	4.2
	6X0.75	5.2
NORMAL	6X1	5
	7X0.75	6.2
NORMAL	7X1	6

PAS	MARIME	BURGHIU NECESAR
	8x0.75	7.2
	8X1	7
NORMAL	8X1.25	6.8
	9X0.75	8.2
	9X1	8
NORMAL	9X1.25	7.8
	10X1	9
	10X1.25	8.8
NORMAL	10x1.5	8.5
NORMAL	11X1.5	9.5
	12X1	11
	12X1.25	10.8
	12X1.5	10.5
NORMAL	12X1.75	10.2
	14X1	13
	14X1.25	12.8

PAS	MARIME	BURGHIU NECESAR
	14X1.5	12.5
NORMAL	14X2	12
	15X1	14
	16X1	15
	16X1.5	14.5
NORMAL	16X2	14
	17X1	16
	18x1	17
	18X1.5	16.5
NORMAL	18X2.5	15.5
	20x1	19
	20x1.5	18.5
NORMAL	20x2.5	17.5
	22x1	21
	22x1.5	20.5
NORMAL	22X2.5	19.5

PAS	MARIME	BURGHIU NECESAR
	24x1	23
	24x1.5	22.5
	24x2	22
NORMAL	24x3	21
	25x1.5	23.5
	26x1.5	24.5
	27x1	26
	27x1.5	25.5
	27x2	25
	27X3	24
	28X1.5	26.5
	28X2	26
	30X1	29
	30x1.5	28.5
	30x2	28
NORMAL	30x3.5	26.5

TAROZI GAZ

PAS	BURGHIU NECESAR
1/16"	6.7
1/8"	8.8
1/4"	11.4
3/8"	15.2
1/2"	18.8
5/8"	20.25
3/4"	24.25
7/8"	28
1"	30.5